

## ENGLISH

### PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USE

Your ESTHETIC has been specially designed for the removal of unwanted facial hair. Do not use it on other areas of the body, nor for removing eyelashes, eyebrows or hair from the nostrils. When your appliance is switched on, keep it away from clothes and accessories and keep it out of the reach of children.

### Always consult your doctor before use if you have any of the following:

wounds, acne, eczema, psoriasis, a prevalence to allergies, raised moles, veining or high coloring (Rosacea), reduced immunity of the skin, e.g. if you have diabetes or are pregnant, hemophilia or immune deficiency. Please note that the use of hormones and contraceptive pills can affect hair growth, color and thickness. These changes cannot be caused or promoted by the use of your ESTHETIC.

### BATTERIES:

Your appliance works on 2 LR6 1.5V AA Alkaline batteries.

- Ensure the appliance is switched off (fig. 1)
- Remove the battery cover by pulling it backward (fig. 2)
- Insert the 2 batteries exactly as shown in the battery housing and replace the cover (fig. 2)

### BATTERY CARE:

To avoid damage to your appliance due to battery leakage, remove the batteries after use if you do not expect to use it again for month or more and do not leave weak or ageing batteries in the appliance.

### EPILATION:

Clean the coil with the small brush included in the set. Clean your face thoroughly and dry your skin. The area of skin to be epilated must be free from any cream, lotion or make up. A completely dry and clean skin area provides the best results. Turn on the appliance, stretch the skin on the area to be epilated. Now, pressing very gently, move the appliance against

Now, pressing very gently, move the appliance against the direction of hair growth. Don't keep your appliance for a long time on the same place to remove a difficult hair, it could heat the skin too much. Retry at the next turn. Never apply undue pressure, which is unnecessary and may cause irritation.

### AFTER EACH USE:

Clean your face and let it dry. Clean the coil again with the brush provided. Open the coil lid, so you can brush out all hairs completely (fig. 3).

### CAUTION:

Never wash or immerse the appliance or leave any part of it to stand in water.

### AFTER HAIR REMOVAL:

You may feel some irritation or experience some reddening of the skin. This is quite normal after removing hair by the roots - as with ordinary tweezers. The makers recommend that you use your appliance last thing at night, so that if reddening occurs it will disappear by morning. Also it is important not to expose your skin to sunlight for some hours after hair removal.

### GUARANTEE

**Epilady 2000 L.L.C.** makes every effort to ensure that its products are manufactured without any defect. However, in the rare event of defects due to faulty workmanship or materials, we guarantee to repair or replace the product, or any part thereof, free of charge.

- This guarantee is granted to the original purchaser only and is valid for one year from the date of purchase indicated below by the sales agent.

- This guarantee does not apply if the product is altered or repaired or otherwise tampered with by unauthorized persons and/or is used other than in accordance with the manufacturer's instructions and/or is subjected to other than reasonable use of a product of its nature.

- This guarantee in no way affects your rights under statutory law.

- This guarantee is valid only when accompanied by the original purchase slip.